

Water Sampling Techniques to Identify Ground Water Contaminants
(1 hr of Certified Crop Advisor continuing education credits)

Why does **how** you sample matter?

Monitoring

Ground Water Sampling and


How frequently should you sample?

How often you should sample depends on the purpose of the sampling and the depth of the aquifer formations from which the well draws water.

Large Production: When screening the water quality in large production wells that pump water from aquifer formations more than 100 feet deep, sampling every year to every few years is sufficient because changes in water quality for such a well will be gradual.

Domestic Wells: Shallower wells, particularly domestic wells with smaller pumping rates, should be sampled once or twice a year because they are more prone to short-term variations in groundwater quality and contamination.

Maintenance or Repair: If problems with well bacteria, well degradation, or iron (from a rusting well casing) have been identified and a well maintenance program has been implemented by a licensed contractor, frequent sampling may be necessary regardless of well depth in order to monitor the success of the well rehabilitation.



Six Steps to Sampling

1. Sampling Preparations: Before you take a water sample, the field sampling equipment should be cleaned and calibrated.
2. Accessing the Well:
 - a. Monitoring wells: usually secured with a locking cover or bolted metal housing, either at ground level in a traffic-rated utility or well box or inside a 2- to 3-foot-tall metal pipe housing. Inside the housing, the actual monitoring well (usually a 2- or 4-inch PVC pipe) is sealed with an expandable rubber plug that can be locked tight. The plug is sealed with a keyed padlock
 - b. Production wells: Ideally, a sample valve or spigot will be located in the water pipeline between the wellhead and the water storage or pressure tank. In many domestic wells, however, the closest access to water from the well is at the exit point of the water pressure tank or at a water faucet inside the house. When testing ground water, the water sample ideally should not be collected from the tap. If the house is on a water treatment or water softening system, either of which involves chemical alteration of the water, the sample should be taken at a point in the distribution system that comes before the water enters any treatment and as close to the well as possible. If you can only draw a sample at the outflow of a pressure or storage tank, you should flush the tank prior to sampling
 - c. Irrigation Wells: The easiest access to irrigation wells is often at the flood gates or sprinkler system hookup. Further downstream, water quality changes may result from the water's interaction with irrigation pipe or filtration systems. Major mineral salt content and nitrate are

not usually affected by piping or filtration, but pH, bacterial concentrations, iron concentration, and trace constituents may be affected.

- d. **Well Casing:** In some cases it may be possible to gain access to the well casing through an access pipe. If you are sampling directly from a production well by means of a portable submersible pump, bailer, or other collection device, the production well turbines or pumps must be shut off and considerable care must be taken to avoid tangling or wedging the sampling equipment between the production line, electric cables, drive shaft, and other equipment typically suspended in a well casing.

3. Measuring the Water Level:

- a. Measure the depth to the water table in the well (water level measurement). Water level information is important because changes in water levels may be directly linked to groundwater quality changes. Ask to review the (historical) record of water level measurements together as well as the well construction file.
- b. Both domestic and irrigation wells should have a small access tube to the inside of the well casing through which a water level meter can be inserted. Groundwater levels are measured to an accuracy of one one-hundredth of a foot (0.01 ft) using a survey-grade groundwater level meter. For less precise measurements, homeowners without a meter can use a long measuring tape marked with chalk (lower the tape until it is well into the water table, measure the depth, then subtract the wetted length of the chalk to compute actual depth to water) or a pair of shielded wires with an ohmmeter attached (when the stripped tips of the two wires touch the water table, a small current begins to flow that can be registered with the ohmmeter).
- c. For water level readings, measure the depth to water from a fixed and identifiable reference point at the top of the well. For a monitoring well, the standard reference point is the north side of the top of the PVC casing (shel 10.5 (the top of the protective housing around the PVC pipe. Reference points should be marked to ensure consistency between sampling times (Figure 3). For production wells, the reference point can be the top of the access tube or access hole to the well casing. Wo()0.5(ar)-1.5 6.eadiing. W (he)0.5 (dept)0.5 (h)0.6 (t)0.5 (o)0 (i)1.5 (t)0.5 ra

- iii. Peristaltic pumps. For small-diameter wells with water table depths of less than 20 feet.
- iv. Air-lift samplers. Device pressurizes the well casing to force a water sample to the surface; not suited for volatile compounds.
- v. Gas-operated bladder pumps. For small-diameter, deep wells; needs a source of nitrogen gas.
- vi. Bailers. Inexpensive, available in a wide variety of materials and diameters, but low-volume removal, degassing and aeration is possible though problematic for many trace constituents.

5. Collecting the Sample: The water sample must be collected within six hours of purging, and usually is collected immediately after purging. If an adjustable-speed pump is used, the pumping rate is lowered prior to sampling to avoid degassing or aeration of the water sample. Similarly, a faucet or valve should be turned down after purging such that the water will flow slowly and without aeration. Before the sample containers are filled, they should be properly labeled. A sample is collected directly from the bailer, pump discharge, faucet, or valve. The sampling container should be completely filled, and then capped and properly stored. Finally, the sample log should be completed and all locking covers, locks, and housing covers should be secured safely to ensure protection of the well.

6. Preserving the Sample: Since water samples are not immediately analyzed in the field, they typically require preservation. Proper preservation ensures that the water quality of the sample does not change between the time of collection in the field and the time of analysis in the laboratory. Preservation methods suppress chemical reactions that can occur in sample water due to degassing (lower partial pressure of dissolved oxygen, carbon dioxide, etc.) or to exposure to heat and light. Which preservation method is best suited to a given sample depends on the water quality parameters to be measured and the amount of time between collection and analysis. If a water sample is analyzed for multiple parameters that require different preservation methods, it may be necessary to take several samples using separate containers. Preservation usually also includes cooling the sample to 4°C (40°F). Samples must remain cool during shipping and storage. It is best to deliver the samples to the laboratory within one to two days of sampling. If samples are shipped, the sealed sample containers are put into ice chests that are then packed with ice and transported to the analytical laboratory by express delivery service. At the laboratory, the samples are logged in, given sample ID numbers, and kept cool until they can be analyzed.